


Safety Cover Measuring & Installation Instructions

- First measure the length of the pool.
- Then measure the width of the pool.





• Now measure the corners







• Then measure the length and width of the step













- Locate and identify any obstructions
 - Waterfalls
 - Raised walls
 - Rock walls
 - Non removable ladder, step rails
 - Non removable diving board
 - Planter areas








MEASUREMENT OF EVERY ROCK OR OBSTACLE WITH 36" OF POOL EDGE IS ABSOLUTELY CRITICAL.



MEASUREMENT OF EVERY ROCK OR OBSTACLE WITHIN 36" OF POOL EDGE IS ABSOLUTELY CRITICAL



MEASURE TO CENTER OF TUBE ON LADDER, AND NOTE WHAT THE TUBE DIAMETER IS.



Techniques For Measuring A Freeform



• Establish reference points A & B, then measure distance between the two





• Mark pool perimeter every 3'






• Record distance: Distance from A to point and distance from B to point.






• A & B must be located on


supplied drawing with the distance between them.






• What happens if A & B are reversed or Flipped.








 What happens if A & B fade in toward pool






• How to locate a raised wall.






- Any and All obstructions must be located using A & B point to point.
 - NOTE: IN EVERY CASE
 POSSIBLE PICTURES
 SHOULD BE SUPPLIED.





- For a raised spa, locate using:
 - A&B points
 - Height above the deck
 - Radius to the outside of the spa





Safety Cover Installation



- Remove any and all obstructions that were not accounted for in cover design and manufacture.
 - Ladders
 - Slides
 - Diving boards



• If a slide or diving board cannot be removed insure that Y strap is used.



• Mark center of pool ends.







• Place cover on pool deck.





• Spread cover out over pool.







• Measure overlap on each side of pool





• Calculate anchor distance from pool edge.





 Strike chalk lines on sides and ends where anchors are to be set.





 Work from center strap alternating from side to side, transfer strap location to deck





• Drill anchor holes at each strap point. DO NOT DRILL CORNERS






 Vacuum holes: To remove dust to ensure depth is open to set anchors.





• Lube threads





• Set anchors









 Attach spring to strap using buckle or D ring depending the type of spring ordered.







 Use Installation Rod to install all springs to anchors





- Attach springs to the anchors as follows
 - A. Start at center of the end of the pool, and work toward the corners. Repeat on other side DO NOT ATTACH CORNERS





- Attach springs to the anchors as follows
 - B. Start at center of pool side, and work toward corners.
 Repeat on other side DO NOT ATTACH
 CORNERS





- Attach Step anchors
- Attach Corner anchors





• Attach Corner anchors





- Corner anchors
 - Drill anchor holes at the strap point.
 - Vacuum holes.
 - Set anchors
 - Lube threads







